

# X5 Prime OCS Datasheet

Built-In I/O: 4 Digital DC Inputs, 4 Digital DC Outputs, 4 Analog Inputs

MAN1363 R21

24 JUL 2023



**Part Number: HE-XP5**

## User Manual and Add-Ons

Find the documents via the [Documentation Search](#).

Part #	Description
MAN1039	HE-X5 & HE-X5 Prime User Manual
HE-XCK	Programming Cables
HE-FBD001	Ferrite core for filtering out electrical noise.
HE200MJ2TRM	Adapter, RJ45 (8P8C) male to 8-position terminal strip.
HE-XRJ503	RJ45 to 5-pin Cable - 3ft
HE-XRJ509	RJ45 to 5-pin Cable - 9ft
HE-XRJ003	RJ45 to RJ45 Ethernet Patch Cable 3ft
HE-XRJ009	RJ45 to RJ45 Ethernet Patch Cable 9ft

## Backup Battery

The XL6 Prime uses a Renata CR2032 lithium battery to run the Real Time Clock for 7-10 years. Please reference **MAN1039** for more details about the battery.

## Power Supply Note

Very short dips (about 100 milliseconds) in the input power can result in output that are ON to remain ON for about 1 second while the unit cycles power. Selecting a power supply that prevents these short glitches or using remote I/O can eliminate this issue.

## Table of Contents

User Manual and Add-Ons .....	1
Backup Battery .....	1
Power Supply Note .....	1
<b>TECHNICAL SPECIFICATIONS .....</b>	<b>2</b>
General Specifications .....	2
Control and Logic .....	3
Display .....	3
Connectivity .....	3
USB Webcams .....	3
<b>CONTROLLER OVERVIEW .....</b>	<b>4</b>
Overview of OCS .....	4
Power Wiring .....	5
<b>DIGITAL &amp; ANALOG I/O SPECIFICATIONS .....</b>	<b>6</b>
Digital DC Inputs .....	6
Analog Inputs .....	7
Digital DC Outputs .....	8
Analog In Tranzorb Failure .....	8
<b>WIRING: INPUTS AND OUTPUTS .....</b>	<b>9</b>
Digital Input Wiring .....	9
Digital Output Wiring .....	9
Analog Inputs .....	10
Built-In I/O Register Map for X5 .....	11
<b>COMMUNICATIONS .....</b>	<b>12</b>
Serial Communication .....	12
Dip Switches .....	13
CAN Communications .....	13
Ethernet .....	14
microSD Slot .....	14
USB Ports .....	14
<b>DIMENSIONS &amp; INSTALLATION .....</b>	<b>15</b>
X5 & X5 Prime Dimensions .....	15
Installation Procedure .....	16
<b>SAFETY &amp; MAINTENANCE .....</b>	<b>17</b>
Warnings .....	17
FCC Compliance .....	17
Technical Support .....	17
Precautions .....	18

## TECHNICAL SPECIFICATIONS

### General Specifications

Required Pwr. (steady state)	118.1mA @ 24VDC
Required Pwr. (inrush)	20A for < 1 ms at 24VC DC Switched
Primary Pwr. Range	10-30VDC
Required Pwr with Backlight @ 50%	85.6mA @ 24VDC
Backlight OFF	83.6mA @ 24VDC
Battery	Replaceable Coin Cell
Clock Accuracy	+/-20 ppm maximum at 25°C (+/- 1 min/month)
Real Time Clock	With Battery
Battery Life	5-10 Yrs Not Replaceable
Relative Humidity	5-95% non-condensing
Operating Temp.	-10°C to +60°C
Storage Temp.	-30°C to +70°C
Altitude	Up to 2000m
Rated Pollution Degree	Evaluated for Pollution Degree 2 Rating
Weight	10 oz / 271 g
Certifications (CE)	<a href="#">North America</a> or <a href="#">Europe</a>
Enclosure Type	Type 1, 3R, 4, 4X, 12, 12K, & 13

## Control and Logic

Control Lang. Support	Advanced Ladder Logic; Full IEC 61131-3 Languages
Logic Program Size	2MB, Max.
Scan Rate	0.02ms/kB
Online Programming Changes	Supported in Advanced Ladder
Digital Inputs	2048
Digital Outputs	2048
Analog Inputs	512
Analog Outputs	512
Gen. Purpose Registers	50,000 (words) Retentive; 16,384 (bits) Non-Retentive

## Display

Display Type	Resistive 4.3" Touchscreen: 450cd/m <sup>2</sup> (nits)
Resolution	WQVGA (480 x 272)
Color	65K Color
Screen Memory	22MB
User-Program. Screens	1023
Backlight	White LED

## Connectivity

Serial	2 (1xRS232, 1x2-wire RS485)
CAN	CAN 125kbps – 1Mbps
Ethernet	1 x 10Mbps/100Mbps
USB (2)	1 X Mini B for Programming. 1 X USB A for drives, Wi-Fi, or cameras
microSD	1 x SD, SDHC, SDXC in FAT32 format

## USB Webcams

USB Webcams supported should support the UVC (USB Video class) protocol for the OCS to be able to display video. Most USB based video devices support this today. Special feature such as zoom and high definition are not supported by the OCS.

# CONTROLLER OVERVIEW

## Overview of OCS




1. Power
2. Input Connector
3. Output Connector
4. CAN Port
5. Serial Ports
6. DIP Switches
7. Ethernet Port
8. microSD Slot
9. USB A Port
10. USB Mini-B Port

**NOTE:** See "Precautions" on page 18 about USB and grounding.

## Power Wiring

**NOTE:** The Primary Power Range is 10VDC to 30VDC.



Primary Power Port Pins		
PIN	Signal	Description
1	Ground	Frame Ground
2	DC-	Input Power Supply Ground
3	DC+	Input Power Supply Voltage

### DC Input/Frame

- Solid/Stranded Wire: 12-24 awg (2.5-0.2mm)
- Strip length: 0.28" (7mm)
- Torque, Terminal Hold-Down Screws: 4.5 – 7 in-lbs (0.50 – 0.78 N-m)

DC- is internally connected to I/O V-and CAN V-. A Class 2 power supply must be used.

### Power Up

1. **Optional:** Attach ferrite core with a minimum of two turns of the DC+ and DC- signals from the DC supply that is powering the controllers.



2. Connect Pin 1 to Earth Ground
3. Apply DC power to pins 2 & 3.

## DIGITAL & ANALOG I/O SPECIFICATIONS

### Digital DC Inputs

Inputs per Module	4	
Commons per Module	1	
Input Voltage Range	0VDC - 24VDC	
Absolute Max. Voltage	30VDC Max.	
Input Impedance	10k $\Omega$	
Input Current	Positive Logic	Negative Logic
Min. ON Current	0.8mA	-1.6mA
Max. OFF Current	0.3mA	-2.1mA
Min. ON Input	8VDC	
Max. OFF Input	3VDC	
OFF to ON Response	2ms min*	
ON to OFF Response	2ms min*	
Galvanic Isolation	None	
Logic Polarity	Pos. or Neg. based on configuration	
I/O Indication	None	
High Speed Counter	4 HSC	
Maximum Frequency	500kHz	
Connector Type	3.5mm Pluggable Cage Clamp	

\*all values updated 1x per scan

## Analog Inputs

Number of Channels	4
Input Signal Range	4-20mA, 0-20mA DC, 0-10VDC
Input Raw Value Range	0-32,000
Abs. Max. Input Voltage	-0.5 to 12VDC
Galvanic Isolation	None
Input Impedance (clamped at -0.5 to 12 Vdc)	<b>mA:</b> 50Ω <b>V:</b> 500kΩ
Nominal Resolution	12 Bits
Conversion Speed	All Channels Once per OCS Scan
Analog Max Error @ 25°C	1.5% of full scale

## Digital DC Outputs


Outputs per Module	4
Commons per Module	1
Output Type	Half-Bridge
Absolute Max. Voltage	30VDC Max.
Output Protection	Short Circuit & Overvoltage
Max. Output Current per Point	0.5A
Max. Total Current	2A Total Current
Max. Output Supply	30VDC
Min. Output Supply	10VDC
Max. Voltage Drop at Rated Current	0.25VDC
Min. Load	None
I/O Indication	None
Galvanic Isolation	None
OFF to ON Response	500ns min*
ON to OFF Response	500ns min*
PWM Out	500kHz Max.
Output Characteristics	Current Sourcing (Pos. Logic)

\*all values updated 1x per scan

## Analog In Tranzorb Failure

A common cause of Analog Input Tranzorb Failure on Analog Inputs: If a 4-20mA circuit is initially wired with loop power, but without a load, the analog input could see 24VDC. This is higher than the rating of the tranzorb. This


can be solved by NOT connecting loop power prior to load connection, or by installing a low-cost PTC in series between the load and analog input.





# WIRING: INPUTS AND OUTPUTS

## Digital Input Wiring




**Positive Logic vs. Negative Logic Wiring:** The X5 & X5 Prime can be wired for Positive Logic inputs or Negative Logic inputs.

Digital inputs may be wired in either a Positive Logic or Negative Logic fashion as shown. The setting in the Cscape Hardware Configuration for the Digital Inputs must match the wiring used in order for the correct input states to be registered. No jumper settings are required for X5 & X5 Prime. When used as a normal input and not for high speed functions, the state of the input is reflected in registers %I1 – %I4.

Digital inputs may alternately be specified for use with High Speed Counter functions, also found in the Hardware Configuration for Digital Inputs. Refer to the X5 & X5 Prime User Manual (**MAN1039**) for full details.


## Digital Output Wiring



Digital outputs are Positive Logic. If an output is turned on, the voltage supplied at the Vext terminal is applied to that output. When used as normal outputs, the state of the output may be controlled using the registers %Q1, %Q2, %Q3, and %Q4.


The first two digital outputs may alternately be specified for use as Pulse Width Modulation (PWM) or Stepper outputs. The configuration for these functions is found in the Cscape Hardware Configuration for Digital Outputs.

# Analog Inputs



Raw input values for channels 1-4 are found in the registers as Integer- type data with a range from 0 – 32000.

Analog inputs may be filtered digitally with the Filter Constant found in the Cscape Hardware Configuration for Analog Inputs. Valid filter values are 0-7 and act according to the following chart:



Data Values	
Input Mode:	Data Format, 12-bit INT:
0-20mA, 4-20mA	0-32000


### Built-In I/O Register Map for X5

FIXED ADDRESS	I/O FUNCTION	X5
%I1	Digital Inputs	1-4
	Reserved	5-16
%Q1	Digital Outputs	1-4
	Reserved	5-16
%AI1	Analog Inputs	1-4
	Reserved	n/a

## COMMUNICATIONS

### Serial Communication

#### MJ1/2 Serial Ports

 <p style="font-size: small; margin-top: 5px;">HG-008</p>	<p>2 Serial Ports on 1 Module Jack (8posn)</p> <p><b>MJ1:</b> RS-232 w/Full Handshaking</p> <p><b>MJ2:</b> RS-485 Half-Duplex</p>
--	---

MJ1 PINS			MJ2 PINS	
PIN	SIGNAL	DIRECTION	SIGNAL	DIRECTION
8	TXD	OUT	--	--
7	RXD	IN	--	--
6	0V	GROUND	0V	GROUND
5	+5V @ 60mA	OUT	+5V @ 60mA	OUT
4	RTS	OUT	--	--
3	CTS	IN	--	--
2	--	--	RX- / TX-	IN / OUT
1	--	--	RX+ / TX+	IN / OUT

**NOTE:** Refer to connector pinout on product

Two serial ports are provided via the single 8-position modular jack labeled “MJ1/2”. MJ1 defaults to one of several methods available to program the controller. It may instead be specified for RS-232 communications with or without hardware handshaking, such as for Modbus Master/Slave, or to communicate to devices such as bar code scanners.


MJ2 may only be used as half-duplex (2-wire) RS-485. The most common use is for Modbus communications, either as a Modbus Master or Modbus Slave, though many other options are also available. Termination for the RS-485 port may be achieved by turning DIP switch 1 to the ON position. Only the two devices on either end of the RS-485 daisy-chain should be terminated.

## Dip Switches

DIP Switches				
PIN		NAME	FUNCTION	DEFAULT
1		RS-485 Termination	ON = Terminated	OFF
2		CAN Termination	ON = Terminated	OFF
3		Bootload	Always OFF	OFF

The DIP switches are used to provide a build-in termination to both the MJ2 port and CAN port if needed. The termination for these ports should only be used if this device is located at either end of the multidrop/daisy-chained RS-485 network or CAN bus.

## CAN Communications


	<p><b>CAN:</b> Modular jack (8posn)</p>
--	---

CAN Pin Assignments	
PIN	SIGNAL
8	No Connection
7	Ground
6	Ground
5	No Connection
4	No Connection
3	Ground
2	CAN Data Low
1	CAN Data High

The CAN port is provided via the single 8-position modular jack labeled "CAN". It may be used to communicate with other OCS products using Horner's CsCAN protocol. Additionally, remote expansion I/O such as SmartRail, SmartBlock, OSC IO, and SmartStix may be implemented using the CsCAN protocol.

Termination for the CAN port may be achieved by turning DIP switch 2 to the ON position. This should only occur if the X5 is at one end of the CAN daisy-chain or the other. Only the two devices on either end of the CAN daisy-chain should be terminated.

## Ethernet



10/100 Ethernet port with automatic MDI-X (crossover detection) is provided via the single 8-position modular jack labeled “LAN”. Several features are available for use over Ethernet, such as WebMI, Modbus TCP/IP, Ethernet/IP, SMTP (E-mail), and more. Ethernet configuration is done via the Cscape Hardware Configuration, though temporary Ethernet configuration may be done through the System Menu directly on the X5.

For more information on Ethernet, available features and protocols, refer to the Ethernet Supplement (**SUP0740**).

## microSD Slot

A microSD card may be used for data and alarm logging, historic trending, program loading, firmware updates, and many other features. Supported types of microSD cards are SD, SDHC, and SDXC as long as the format of the card file system is FAT32. Card formatting may be done by the controller if no other means are available to do so.


## USB Ports

The **USB Mini B port** is provided as one of several ways to program the X5. Drivers for Windows to recognize the controller as a virtual COM port are automatically installed with Cscape software.

The **USB A port** is provided to be able to use a thumb drive for data and alarm logging, historic trending, firmware updates, and many other purposes. Files may also be transferred between a USB thumb drive and the installed microSD card, Wi-Fi module, or USB cameras.

## DIMENSIONS & INSTALLATION

### X5 & X5 Prime Dimensions



Panel Tolerance +/- 0.5mm

## Installation Procedure

- This equipment is panel mounted and is meant to be installed in an enclosure suitable for the environment, such that the back of the equipment is only accessible with the use of a tool.
- Requires a Class 2 Power Source.
- This equipment is suitable for use in Class I, Division 2, Groups A, B, C and D; Class II, Division 2 Groups F and G; and Class III Hazardous Locations or Non-Hazardous Locations only.

The X5 utilizes a clip installation method to ensure a robust and watertight seal to the enclosure. Follow the steps below for the proper installation and operation of the unit.

1. Carefully locate an appropriate place to mount the X5. Be sure to leave enough room at the top of the unit for insertion and removal of the microSD™ card.
2. Carefully cut the host panel per the diagram , creating a 90.5mm x 119.5mm (with a tolerance of +/- 0.5mm) opening into which the X5 may be installed. If the opening is too large, water may leak into the enclosure, potentially damaging the unit. If the opening is too small, the OCS may not fit through the hole without damage.
3. Remove any burrs and or sharp edges and ensure the panel is not warped in the cutting process.
4. Install and tighten the four mounting clips (provided in the box) until the gasket forms a tight seal. For standard composite mounting clips (included with product), use a torque rating of 2-3 in-lbs (0.23- 0.34 Nm). For optional metal mounting clips, use a torque rating of 4-8 in lbs (0.45-0.90 Nm).
5. Connect I/O, communications cables to the serial port, USB ports, and CAN port as required.



## SAFETY & MAINTENANCE

### Warnings

1. To avoid the risk of electric shock or burns, always connect the safety (or earth) ground before making any other connections.
2. To reduce the risk of fire, electrical shock, or physical injury, it is strongly recommended to fuse the voltage measurement inputs. Be sure to locate fuses as close to the source as possible.
3. Replace fuse with the same type and rating to provide protection against risk of fire and shock hazards.
4. In the event of repeated failure, do NOT replace the fuse again as repeated failure indicates a defective condition that will NOT clear by replacing the fuse.
5. Only qualified electrical personnel familiar with the construction and operation of this equipment and the hazards involved should install, adjust, operate, or service this equipment.
6. Read and understand this manual and other applicable manuals in their entirety before proceeding. Failure to observe this precaution could result in severe bodily injury or loss of life.
7. **WARNING:** Battery may explode if mistreated. Do not recharge, disassemble, or dispose of in fire.
8. **WARNING:** EXPLOSION HAZARD- Batteries must only be changed in an area known to be non-hazardous.
9. **WARNING:** Do not disconnect while circuit is live unless are is know to be non-hazardous.

### FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

### Technical Support

North America	Europe
1 (317) 916-4274 (877) 665-5666 <a href="http://www.hornerautomation.com">www.hornerautomation.com</a> <a href="mailto:APGUSATechSupport@heapg.com">APGUSATechSupport@heapg.com</a>	+353 (21) 4321-266 <a href="http://www.hornerautomation.eu">www.hornerautomation.eu</a> <a href="mailto:technical.support@horner-apg.com">technical.support@horner-apg.com</a>

## Precautions

All applicable codes and standards need to be followed in the installation of this product. Adhere to the following safety precautions whenever any type of connection is made to the module:

1. Connect the safety (earth) ground on the power connector first before making any other connections.
2. When connecting to the electric circuits or pulse-initiating equipment, open their related breakers.
3. Do NOT make connection to live power lines.
4. Make connections to the module first; then connect to the circuit to be monitored.
5. Route power wires in a safe manner in accordance with good practice and local codes.
6. Wear proper personal protective equipment including safety glasses and insulated gloves when making connections to power circuits.
7. Ensure hands, shoes, and floor are dry before making any connection to a power line.
8. Make sure the unit is turned OFF before making connection to terminals.
9. Make sure all circuits are de-energized before making connections.
10. Before each use, inspect all cables for breaks or cracks in the insulation. Replace immediately if defective.
11. Use copper conductors in Field Wiring only, 60/75°C.
12. Use caution when connecting controllers to PCs via serial or USB. PCs, especially laptops, may use “floating power supplies” that are ungrounded. This could cause a damaging voltage potential between the laptop and controller. Ensure the controller and laptop are grounded for maximum protection. Consider using a USB isolator due to voltage potential differences as a preventative measure.