

HE959DIQ512			
<input type="radio"/>	I1	0V	<input type="radio"/>
<input type="radio"/>	I2	0V	<input type="radio"/>
<input type="radio"/>	I3	0V	<input type="radio"/>
<input type="radio"/>	I4	0V	<input type="radio"/>
<input type="radio"/>	R1	R1	<input type="radio"/>
<input type="radio"/>	C1	C1	<input type="radio"/>
<input type="radio"/>	R2	R2	<input type="radio"/>
<input type="radio"/>	C2	C2	<input type="radio"/>
<input type="radio"/>	R3	R3	<input type="radio"/>
<input type="radio"/>	C3	C3	<input type="radio"/>
<input type="radio"/>	R4	R4	<input type="radio"/>
<input type="radio"/>	C4	C4	<input type="radio"/>