

HE959DIQ616

<input type="radio"/>	I1	Q1	<input type="radio"/>
<input type="radio"/>	I2	Q2	<input type="radio"/>
<input type="radio"/>	I3	Q3	<input type="radio"/>
<input type="radio"/>	I4	Q4	<input type="radio"/>
<input type="radio"/>	0V	V1	<input type="radio"/>
<input type="radio"/>	0V	0V	<input type="radio"/>
<input type="radio"/>	I5	Q5	<input type="radio"/>
<input type="radio"/>	I6	Q6	<input type="radio"/>
<input type="radio"/>	I7	Q7	<input type="radio"/>
<input type="radio"/>	I8	Q8	<input type="radio"/>
<input type="radio"/>	0V	V2	<input type="radio"/>
<input type="radio"/>	0V	0V	<input type="radio"/>