



SmartRail

0-10V, 4-20mA Analog Input Module


HE599ADC170

12-Bit Resolution

1 Specifications

Specifications	
ADC170	
Number of Channels	4
Input Ranges	0-10V, 4-20mA, 0-20mA
Absolute Max. Inputs	+/-15V, +/-30mA
Resolution	12-Bit (2.5mV, 4uA, 5uA)
Input Impedance	1MΩ (voltage), 250Ω (current)
Accuracy	< +/-0.5%
Isolation	Photocoupler (Input/Power)
Conversion Time	1.5mS/ch
Backplane Power Consumed	50mA @ 5V
External Power Required	62mA @ 24V (+/-10%) CLASS 2 POWER SUPPLY ONLY
Terminal Type	M2 Screw Type, Removable 11-posn
Optional Spring Clamp Terminal	HE599TRM011, 11 position
Terminal Torque Rating	0.22 to 0.25 N-m 1.95 to 2.21 in-lb
Accepted Wire Size	16-28AWG (use copper)
Wire Stripping Length	7mm
Storage Temp.	-25° to 70° Celsius
Operating Temp.	0° to 55° Celsius
Relative Humidity	5 to 95% Non-condensing
Dimensions WxHxD	20mm x 90mm x 60mm 0.79" x 3.54" x 2.36"
Weight	67g (2.4 oz.)
CE & UL Compliance	CE, UL & C-UL Class I, Div 2 Groups A, B, C & D

2 Wiring – I/O



ADC170 LED Status Indication	
LED	Meaning
RUN	ON = Normal Operation
	FLASH = I/O Error
	OFF = No Power or I/O Error

3 Configuration DATA

The SmartRail ADC170 features a dip switch on the front of the unit for selecting voltage (0-10V) or current (4-20mA or 0-20mA) on a per channel basis. In addition to the physical dip switch, Cscope (9.1 or later) must be used for software configuration as well. The following parameters are configurable in Cscope for the ADC170:

Cscope Configuration Data – Selectable per channel	
Parameter	Selections
Channel Enable	Enable
	Disable
Data Type	4-20mA
	0-20mA
	0-10V
Data Range	0-4000
	-2000 to +2000
	0 to 1000 (for 4-20mA type)
	0 to 1000 (0-20mA or 0-10V type)

4 Installation / safety

This equipment is suitable for use in Class I, Division 2, Groups A, B, C and D or Non-hazardous locations only

WARNING - EXPLOSION HAZARD -

Do not disconnect equipment unless power has been removed or the area is known to be non-hazardous

WARNING - EXPLOSION HAZARD -

Substitution of any component may impair suitability for Class I, Division 2

WARNING – POSSIBLE EQUIPMENT DAMAGE

Remove power from the I/O Base and any peripheral equipment connected to this local system before adding or replacing this or any module.

- a. All applicable codes and standards should be followed in the installation of this product.
- b. Shielded, twisted-pair wiring should be used for best performance.
- c. Shields should be grounded at one end only, preferably at the end providing the best noise shunting.
- d. Use the following wire type or equivalent: Belden 8441.

For detailed installation and a handy checklist that covers panel box layout requirements and minimum clearances, refer to the hardware manual of the controller you are using.

When found on the product, the following symbols specify:



5 Technical Support

Technical Support at the following locations:

North America:
 Tel: 317 916-4274
 Fax: 317 639-4279
 Web: <http://www.heapg.com>
 Email: techspt@heapg.com

Europe:
 Tel: +353-21-4321266
 Fax: +353-21-4321826
 Web: <http://www.horner-apg.com>
 Email: tech.support@horner-apg.com

No part of this publication may be reproduced without the prior agreement and written permission of Horner APG, Inc. Information in this document is subject to change without notice.