

Temperature I/O Module

Mini OCS/RCS

HE500OCS048 / HE500OCS078 HE500RCS078

1 SPECIFICATIONS

Relay Outputs				
Number of Channels	2 N.O. Relays	Maximum Load Current	10A Max.	
	, and the second	(resistive) per channel		
Commons per Module	2	Maximum Leakage Current	5μΑ	
Digital Output Registers Consumed by Cscape (%Q)	1,2 of 8	ON Voltage Level	0.15V	
Isolation (Channel to Channel) (Channel to Common)	500VDC 400VDC	OFF to ON Response	10ms Max.	
Output Type	N.O.	ON to OFF Response	5ms. Max.	
Maximum Load Voltage	250VAC or 30VDC Max.	Protection	Transient voltag suppressor acro contacts.	
Analog Outpus				
Number of Channels	2	Analog Output Registers		
Commons per Module	1	Consumed by Cscape (%AQ)	2	
Output Ranges (including over-range)	20.47mA; Clamped @-0.5 - +33VDC Nominal	Additional error for temperatures other than 25°C	0.01% / °C	
Resolution	12 Bits	Maximum Error at 25°C	0.1%	
Output Voltage	4 - 30VDC	Load Impedance	≤ 1.1kΩ @ 24VDC l Voltage	
SSR Driver				
Number of Channels	2	Minimum Load	None	
Commons per Module	1	OFF to ON Response	1ms.	
Digital Output Registers Consumed by Cscape (%Q)	3,4 of 8	ON to OFF Response	1ms.	
Output Type	Sourcing	Output Characteristics	Current Sourcin	
Output Voltage Maximum Load Current	12VDC Min. 15mA internally	Output Protection	Transient voltag	
per Output	limited		suppressors	


MAN0709-01

Thermocouple Input							
Number of Channels	1 (Shared w	vith RTD)		A/D	Conversion Time	16 channe	ls/second
Commons per Module	1 (for grounding shielded T/Cs only)		•	Analog Input Registers Consumed by Cscape (%AI)		1	
Input Impedance	20Meg Ohm clamped @ ±24VDC		PLC	Update Rate	400ms. For all channels		
A/D Conversion Type	Integra	-		Cold	d Junction	Inter	mal
Types Supported	J, K, T,	& E					
Open Thermocouple Response	Dif			rimum Sustained erential O/L	±15VDC		
Thermocouple Common Mode Range	-10.5VE + 12V			Res	olution	ution 0.05°C	
Thermocouple Type	J				K	Т	
	-210°(C to		-270°C to		-270°	°C to
	770°	C			1380°C	410	°C
	(-346°F to 1418°F)				(-454°F to 2516°F)	(-454 770	
Input Range Temperature	1110	. ,			E	, ,,,	.,
-					-270°C to		
	1010°C						
	(-454°F to 1850°F)						
Accuracy of:	Typical: Under E		nder Extremes: 0°C,	J :±5°C	E : ±1°C		
Types J, K, T, & E	+1°(.			D°C, or full load	K : ±3°C	T: ±4°C	
Note: Accuracy Specificati	ons not guara	inteed belo	ow -10)0°C	C for Thermocouple.		
RTD Input							
Number of Channels	1 (Shared with TC)			Input Transient Protection	Zener/Ca	apacitor	
Commons per Module		1			Resolution	0.05	
Analog Input Registers Consumed by Cscape (%AI)	1			RTD Types Supported	PT1 (100 Ohms at (Alpha 0.00385	0°C, Platinum,	
RTD Excitation Current	200μA, 25% duty cycle		cle		Input Impedance	10Meg clamped @	
RTD Short		efinite			Input Range	-206.2°C to	+856.8°C
Notch Filter	50-60 Hz. Software Selectable		Э		PLC Update Rate	400ms. For a	all channels
A/D Conversion Time	8 channels/second			Accuracy	± 1	°C	
A/D Conversion Type	Integrating			Channel-to- Channel Tracking	0.1	°C	
General Specifications						<u> </u>	
Required Power (Steady State)	4.8W (200m	4.8W (200mA @ 24VDC)			Operating Temperature	0° to 50° Celsius	
Required Power (Inrush)	900mA m	ax. @ 24VI 1ms.	DC fo	r	Terminal Type	Spring Clamp, Removable	
Relative Humidity	5 to 95% Non-condensing		Weight	9.5 oz. (270 g)			
Relative numbers	0 10 00 70 1	von-conde	inoni	9	i vvoigiit	0.0 02.	(3)

Voltage Inputs		
Number of Channels	3	
Commons per Module	1	
Range	±10VDC	
Accuracy	±0.05% of FS	
Input Impedance	1Megohm	
Input type	Pseudo Differential	
A/D Conversion Type	Integrating	
Common Mode Range	± 12VDC, Clamped	

A/D Conversion Time	16 channels/second
Analog Input Registers Consumed (%AI)	3
PLC Update Rate	400ms. For all channels
Common Mode Rejection Ratio	50dB, typical
Maximum Sustained Differential O/L	Limited by CMR
Resolution	300uV

Note: The negative voltage inputs are intended to be used to compensate for small ground errors and should be connected to a potential near ground for best accuracy.




Note regarding Pin C5: The pin is not a THM common but is a thermocouple shielding termination point.

Note: All temperature inputs can be either Thermocouple or RTD inputs.

Warning: Connecting high voltage to any I/O pin may cause high voltage to appear at other I/O pins.

Warning: Wiring the line side of the AC source to loads connected to outputs Q1 through Q2 and the neutral side of the AC source to the output common(s) create a Negative Logic condition, which may be considered an unsafe practice.

3 INTERNAL CIRCUIT SCHEMATIC



- **Note 1:** Specification for transient voltage suppressors (transorbs) used on output circuitry is 400VDC bi-directional 400 watts.
- Note 2: Specification for transient voltage suppressors (transorbs) used on output circuitry is 15VDC, 300 watts.
- Note 3: Specification for transient voltage suppressors (transorbs) used on output circuitry is 30VDC, 500 watts.

Electro-mechanical relays comply with IEC1131-2.

4 CONFIGURATION

Note: The status of the I/O can be monitored in Cscape Software.

Module Setup Tab

The **Module Setup** is used in applications where it is necessary to change the default states or values of the outputs when the controller (e.g., OCS100) enters idle/stop mode.

1. For Digital Outputs: The default turns the outputs OFF when the controller enters idle/stop mode. By selecting the Module Setup tab, each output can be set to either turn ON, turn OFF or to hold the last state. Generally, most applications use the default settings.

Warning: The default turns the digital outputs OFF when the controller enters idle/stop mode. To avoid injury of personnel or damages to equipment, exercise extreme caution when changing the default settings.

The HE800MIX693 digital outputs are assigned as follows assuming a start at %Q1:

%Q1 Relay 1 %Q2 Relay 2 %Q3 SSR Drive 1 %Q4 SSR Drive 2

2. For Analog Outputs: The default sets the output values to zero when the controller enters idle/stop mode. By selecting the Module Setup tab, each output can be set to a specific value or hold the last value. Generally, most applications use the default settings.

Warning: The default sets the output values to zero when the controller enters idle/stop mode. To avoid injury of personnel or damages to equipment, exercise extreme caution when changing the default setting using the **Module Setup** tab.

3. For Temperature Setup

- a. Sensor Type for each channel must match what is physically attached.
- b. Temperature format may be set for various C° or F° ranges.
- c. Filter Constant sets the level of digital filtering according to the chart below.
- d. Reject Rates sets the frequency level for noise rejection at 50 or 60HZ.


I/O Map Tab

The I/O Map describes I/O registers. The I/O Map is <u>not</u> edited by the user.

5 **RELAY OUTPUT CHARACTERISTICS**

Derating Chart for Relay Outputs





Typical Relay Life (Number of Cycles)			
Voltage and Load Type Load Cu		Load Current	
Voltage and Load Type	1 Amp	5 Amp	10 Amp
30VDC Resistive	800K	180K	100K
30VDC Inductive	500K	100K	Not Rated
250VAC Resistive	800K	180K	100K
250VAC Inductive	500K	100K	Not Rated

6 **ANALOG OUTPUTS**

6.1 **Conversion Factor**

The following table describes how program data values are scaled to real-world analog voltage outputs by the module. Given a desired output current, the data value is converted by using the conversion factor from the table. The following formula is used: Data = Output Current (mA) / Conversion Factor

Example:


- 1. The desired output current is 12mA.
- Using the table, the conversion factor for the current range of +20 mA is 0.000625. 2.
- 3. To determine the data value, the formula is used:

Data = Output Current (mA) / Conversion Factor

19200 = 12mA / 0.000625

Conversion of Real-World Outputs into Controller				
Selected Current Output Range Current (mA)		Data	Conversion Factor	
	+20.47	32752		
0 to +20mA	+20.00	32000	0.000625	
	0	0		

6.2 Operating Area



7 VOLTAGE INPUT CONVERSION FACTOR


The following table describes how real-world inputs are scaled into the controller. Given a known input voltage, the register data value may be calculated by using the conversion factor from the table. The following formula is used: **Data = Voltage In / Conversion Factor**

Example: The voltage range is ±10 V:

- 1. The known input voltage is 6 VDC.
- 2. Using the table, the conversion factor for the range of $\pm 10 \text{ V}$ is .0003125.
- 3. To determine the data value, the formula is used: Data = Vin / Conversion Factor 19200 = 6 VDC / 0.0003125

Conversion of Real-World Inputs into Register Values				
Selected Range	Input mA or Volts	Data Out	Conversion Factor	
	> +10.23	32767		
	+10.00	32000		
±10.00 V	0.00	0	0.0003125	
	-10.00	-32000		
	< -10.23	-32768		

8 THERMOCOUPLE / RTD SCALING & CONVERSION FACTOR



Digital Filtering. The illustration above demonstrates the effect of digital filtering (set with Filter Constant) on module response to a temperature change.

For a given module configuration, use the appropriate formula in the table to obtain the actual temperature (°C or °F) that is represented by the value in the %Al register.

Thermocouple	Temperature Conversion		
or RTD Configuration	Celsius	Fahrenheit	
0.05°	°C = %AI / 20 *	°F = %AI / 20 *	
0.1°	°C = %AI / 10	°F = %AI / 10	
0.5°	°C = %AI / 2	°F = %AI / 2	

^{*} Maximum reading in 0.05°F or 0.05°C format is limited to 1638.3 because of %AI resolution.

9 INSTALLATION / SAFETY

- a. All applicable codes and standards should be followed in the installation of this product.
- b. Use the following wire type or equivalent: Belden 8917, 16 AWG or larger for digital I/O; Belden 8441 for analog I/O; Omega TT-J-20-TWSH for thermocouple inputs; and Omega EXTT-3CU-26S for RTD inputs.
- c. Shielded, twisted-pair wiring should be used for best performance (analog I/O).
- d. Shields may be terminated at the module terminal strip.
- e. In severe applications, shields should be tied directly to the ground block within the panel.
- f. Interposing electrical devices (such as relays) in the analog signal path (RTD, Thermocouple) can cause errors due to resistive imbalance.

For detailed installation information, refer to Mini Hardware Manual. A <u>handy checklist</u> is provided that covers panel box layout requirements and minimum clearances.

When found on a product, the following symbols specify:



Warning: Consult user documentation.



Warning: Electrical Shock Hazard.

10 TECHNICAL ASSISTANCE

For assistance, contact Technical Support at the following locations. Please visit our website for manual updates.

North America: (317) 916-4274 www.heapg.com Europe:

(+) 353-21-4321-266 www.horner-apg.com