Image: Properties of the second systemOperator Interface Unit
for GE Fanuc GENIUS™
and Universal Automation
FloPro™

User Manual

Horner APG

FOR NORTH AMERICA ONLY!

MODEL NUMBER: HE6930IU910

SERIAL NUMBER:

WARRANTY REGISTRATION FORM

Please fill out this form and return it to Horner Electric. This information is vital to Horner Electric, should warranty service be required. This document is also used to keep you informed of new product enhancements, software revisions and documentation updates.

IT IS IN YOUR BEST INTEREST TO FILL OUT AND RETURN THIS FORM!

Date of purchase:
Name:
Title:
Company:
Department/Division:
Street Address:
City/State/Zip:
Area Code/Phone Number:
Purchased from (Distributor):

Please indicate the type of application where this product is to be used, check all that apply:

Chemical processing		
Demo equipment		
Education	H	
Energy management	Ħ	
Food processing	Ħ	
Military	H	
Product assembly/testing	Ħ	product:
Waste processing	H	
Other (specify)	H	

Horner APG

FOLD

- -

_

_

_ _ _

_ _ _

STAMP

APG - Controls Division

640 N. Sherman Drive Street Indianapolis, Indiana 46201-3899

ATTN: Warranty Registration Department

FOLD

PREFACE

This manual explains how to use the Horner APG Operator Interface Unit for use with the GE Fanuc Genius I/O Network and Universal Automation's FloPro.

Copyright (C) 1992 Horner APG, LLC., 640 N. Sherman Drive, Indianapolis Indiana 46201-3899. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior agreement and written permission of Horner Electric, Inc.

Information in this document is subject to change without notice and does not represent a commitment on the part of Horner APG, LLC.

Genius, Logicmaster and Series 90 are trademarks of GE Fanuc Automation North America Inc.

FloPro is a trademark of Universal Automation.

IMITED WARRANTY AND LIMITATION OF LIABILIT

Horner APG, LLC. Inc. ("HE") warrants to the original purchaser that the Operator Interface Unit manufactured by HE is free from defects in material and workmanship under normal use and service. The obligation of HE under this warranty shall be limited to the repair or exchange of any part or parts which may prove defective under normal use and service within two years from the date of manufacture or eighteen (18) months from the date of installation by the original purchaser whichever occurs first, such defect to be disclosed to the satisfaction of HE after examination by HE of the allegedly defective part or parts. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE AND OF ALL OTHER OBLIGATIONS OR LIABILITIES AND HE NEITHER ASSUMES, NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR HE, ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OF THIS OPERATOR INTERFACE UNIT. THIS WARRANTY SHALL NOT APPLY TO THIS OPERATOR INTERFACE UNIT OR ANY PART THEREOF WHICH HAS BEEN SUBJECT TO ACCIDENT, NEGLIGENCE, ALTERATION, ABUSE, OR MISUSE. HE MAKES NO WARRANTY WHATSOEVER IN RESPECT TO ACCESSORIES OR PARTS NOT SUP-THE TERM "ORIGINAL PURCHASER", AS USED IN THIS WARRANTY, PLIED BY HE. SHALL BE DEEMED TO MEAN THAT PERSON FOR WHOM THE OPERATOR INTERFACE UNIT IS ORIGINALLY INSTALLED. THIS WARRANTY SHALL APPLY ONLY WITHIN THE BOUNDARIES OF THE CONTINENTAL UNITED STATES.

In no event, whether as a result of breach of contract, warranty, tort (including negligence) or otherwise, shall HE or its suppliers be liable of any special, consequential, incidental or penal damages including, but not limited to, loss of profit or revenues, loss of use of the products or any associated equipment, damage to associated equipment, cost of capital, cost of substitute products, facilities, services or replacement power, down time costs, or claims of original purchaser's customers for such damages.

To obtain warranty service, return the product to your distributor after obtaining a "Return Material Authorization". Include a description of the problem, proof of purchase, post paid, insured and in a suitable package.

ABOUT THE PROGRAM EXAMPLES

The example programs and program segments in this manual are included solely for illustrative purposes. Due to the many variables and requirements associated with any particular installation, Horner Electric cannot assume responsibility or liablity for actual use based on the examples and diagrams. It is the sole responsibility of the system designer utilizing this software to appropriately design the end system, to appropriately integrate the Operator Interface Unit and to make safety provisions for the end equipment as is usual and customary in industrial applications as defined in any codes or standards which apply.

TABLE OF CONTENTS

CHAPTER	1: INTRODUCTION			•		Page 1-
1.1	What You Have .				Page	1-1
1.2	Operator Interface Unit	Features			Page	1-1
1.3	Hardware Description				Page	1-2
1.4	Specifications .				Page	1-2

CHAPTER 2: INSTALLATION

2.1	Mounting Requirements .			•	Page	2-1
2.2	Power Requirements .		•		Page	2-1
2.3	Genius Network Connector.			Page	2-2	
2.4	RS232 Connector		•		Page	2-2
2.5	GENI Configuration .		•		Page	2-3
2.6	OIU DIP Switches		•		Page	2-5
2.7	Logicmaster 90-70 Configurat	ion .			Page	2-6

APPENDIX	A:	PANEL	СИТОИ	г		
APPENDIX	B:	RS-232	CABLE	PINOUT		
APPENDIX	C:	DISPLAY	ABLE	CHARACTERS		
APPENDIX	D:	TECHNIC	AL I	INFORMATION		

CHAPTER 1: INTRODUCTION

Congratulations on your purchase of the Operator Interface Unit. This unit has been designed using state-of-the-art electronic components and incorporates a sophisticated firmware package that gives the Original Equipment Manufacturer (OEM) the ability to utilize this unit with the powerful FloPro Development Package from Universal Automation.

1.1 What You Have

The Operator Interface Unit (OIU) comes complete with the following items:

- A. Assembled OIU module and mounting hardware, including the Genius[™] Network Interface board (GENI).
- B. Aluminum Rear Cover for OIU (Available January, 1993).
- C. This manual.

1.2 Operator Interface Unit Features

The Horner Operator Interface Unit provides the following features:

- A. Gasketed NEMA 4-12 panel with a rugged Lexan[™] overlay, mounting hard ware included.
- B. Four line by 20 character dot-matrix vacuum-fluorescent display.
- C. Tactile feel keypad with numeric support plus special function keys.
- D. Integrated Genius Network Interface board (GENI) for communications on GE Fanuc's Genius Distributed I/O Network.
- E. Acts as a high-performance FloPro Remote Message Unit by communicating over a high speed I/O network instead of a slower, serial based connection.
- F. Standard 9-pin RS232 communications port, for connection to a GE Fanuc PowerMate Motion Controller.
- G. Optional Auxiliary RS232 communications port for communications with a second GE Fanuc PowerMate Motion Controller.

1.3 Hardware Description

The Operator Interface Unit (HE693OIU910) consists of six main components, and one optional component. They are:

- A) Keypad / Mounting plate.
- B) Main Circuit Board.
- C) Vacuum Fluorescent Display Circuit Board.
- D) Power Supply Circuit Board.
- E) Genius Network Interface (GENI) Board.
- F) Aluminum Rear Cover.
- G) (Optional) Auxiliary RS232 Circuit Board. (HE-BUS architecture).

The OIU is a microprocessor-based high-performance communications device. The core of the Main Circuit Board is the Intel 80C152 microprocessor running at 11.0592 MegaHertz. The "firmware" memory is contained in a 27C256 EPROM device. The Main Circuit Board is also equipped with 32K bytes of high-speed static RAM memory. There is no retained memory on the unit. The OIU incorporates a Genius Network Interface board (GENI) that provides the link to the Genius network. The initial OIU power supply accepts a wide AC input range. A standard 24VDC power supply will be standard after January 1, 1993.

1.4 Specifications

Mounting Requirements:	Panel Mounting, NEMA 4-12
Communications:	Genius Network Interface (GENI)
Additional Communications:	Standard RS232 for PowerMate. Optional Auxiliary RS232 for PowerMate
Power Requirements: DC Version	12.5-32 VDC, 14 Watts power max.
Operating Environment:	0 to 60°C. (32 to 140°F). 0 to 95% humidity (non-condesing).
Non-Volatile Memory:	None

CHAPTER 2: INSTALLATION 2.1 Mounting Requirements

The OIU is designed for permanent panel mounting. To install the OIU:

- A. Cut the host panel as described by the drawing in Appendix A.
- B. Make sure all terminal connectors are removed from the OIU.
- C. Remove the aluminum back cover (if installed), by removing the screws securing it to the OIU. Carefully lift the cover off the rear of the OIU a few inches, disconnecting the power terminal from the power supply circuit board. The rear cover should now be completely free of the OIU.
- D. Remove the six #6-32 hex nuts and washers from the outer mounting studs on the rear of the OIU panel.
- E. Insert the OIU module through the front panel cutout. The gasket material should lie between the host panel and the OIU panel.

 F. Install the six #6-32 nuts and lock-washers on the six mounting studs of the OIU. Tighten these nuts until the gasket material forms a tight seal, do not overtighten.

G. Re-install the rear cover (if present). Be sure to re-connect the power terminal to the power supply circuit board. Re-connect all terminal connectors (power and Genius network terminals). This completes the mechanical installation of the OIU module.

2.2 Power Requirements

The OIU power supply requires a DC supply voltage between 12 and 32 volts. A maximum of 14 watts will be drawn by the OIU. The OIU power supply features a 3-position, removeable terminal block. See **Figure 2-1** for connector location. The pinout for this connector is shown below in **Table 2-1**.

Pin	Signal
1	Frame Ground
2	DC Common
3	+12-32VDC

Table 2-1. DC connector pinout



2.3 Genius Network Connector

The OIU is also equipped with a 4-pin Genius bus connector. The mating connector provides screw terminals for each circuit. The pinout for this connector is as follows:

		Pin	Signal	
		1	Serial 1	
		2	Serial 2	
		3	Shield Out	
Tabl	e 2-2.	Genius Ne	workiedonnector Pin	out

2.4 RS232 Connector(s)

The 9-pin "D" connectors on the main circuit board and optional auxiliary port provide RS232 interfaces to two GE Fanuc PowerMate Motion Controllers. The OIU-to-PowerMate cable pinout is shown in Appendix B. For more technical information on the communications between the OIU and the PowerMate, see Appendix D.

2.5 **GENI** Configuration

The GENI board (located on the rear of the OIU module) is equipped with a bank of 8 "DIP" switches. DO NOT CONFUSE THIS DIP SWITCH WITH THE 6-POSITION DIP SWITCH ON THE MAIN CIRCUIT BOARD DESCRIBED LATER. These switches are used to configure the Genuis "bus" address or "Device Number" for the OIU module, and to set the module's Genius baud rate.

Each device on the Genius network must have a unique "Device Number" (0 to 31). The OIU may be configured for any device number, however the following conventions should be followed when chosing the device number for the OIU:

- A. The bus controller is usually configured as device number 31.
- B. The redundant bus controller (if any) is usually configured as device number 30.
- C. The Hand-Held monitor is usually configured as device number 0.

When shipped from the factory, the OIU dip switches are configured for device number 29, and for communication baud rate of 153.6K standard. Multiple OIUs may reside on the network, provided that they have unique device numbers. Available dip switch settings are illustrated in **Figure 2-2**.

8	7	6	5	4	3		2	1						
						I								
		5	4	3	2		1	addres	5	4	3	2	1	addres
		CLOSD	CLOSD	CLOSD	CLOSD	CLC	SD	0	OPEN	CLOSD	CLOSD	CLOSD	CLOSD	16
		CLOSD	CLOSD	CLOSD	CLOSD	OP	EN	1	OPEN	CLOSD	CLOSD	CLOSD	OPEN	17
		CLOSD	CLOSD	CLOSD	OPEN	CLC	DSD	2	OPEN	CLOSD	CLOSD	OPEN	CLOSD	18
		CLOSD	CLOSD	CLOSD	OPEN	OP	ΕN	3	OPEN	CLOSD	CLOSD	OPEN	OPEN	19
		CLOSD	CLOSD	OPEN	CLOSD	CLC	DSD	4	OPEN	CLOSD	OPEN	CLOSD	CLOSD	20
		CLOSD	CLOSD	OPEN	CLOSD	OP	EN	5	OPEN	CLOSD	OPEN	CLOSD	OPEN	21
		CLOSD	CLOSD	OPEN	OPEN	CLC	SD	6	OPEN	CLOSD	OPEN	OPEN	CLOSD	22
		CLOSD	CLOSD	OPEN	OPEN	OP	EN	7	OPEN	CLOSD	OPEN	OPEN	OPEN	23
		CLOSD	OPEN	CLOSD	CLOSD	CLC	SD	8	OPEN	OPEN	CLOSD	CLOSD	CLOSD	24
		CLOSD	OPEN	CLOSD	CLOSD	OP	EN	9	OPEN	OPEN	CLOSD	CLOSD	OPEN	25
		CLOSD	OPEN	CLOSD	OPEN	CLC	DSD	10	OPEN	OPEN	CLOSD	OPEN	CLOSD	26
		CLOSD	OPEN	CLOSD	OPEN	OP	ΕN	11	OPEN	OPEN	CLOSD	OPEN	OPEN	27
		CLOSD	OPEN	OPEN	CLOSD	CLC	SD	12	OPEN	OPEN	OPEN	CLOSD	CLOSD	28
		CLOSD	OPEN	OPEN	CLOSD	OP	ΕN	13	OPEN	OPEN	OPEN	CLOSD	OPEN	29
		CLOSD	OPEN	OPEN	OPEN	CLC	SD	14	OPEN	OPEN	OPEN	OPEN	CLOSD	30
		CLOSD	OPEN	OPEN	OPEN	OP	EN	15	OPEN	OPEN	OPEN	OPEN	OPEN	31
			CLO	7 DSD DSD	CLC OP	6 DSD EN	baud 153.6K 3 8 .	rate extended 4 K						
			OF	PEN	CLC	DSD	76.	8 K						
					OF	PEN	OP	EN	153.6K	standard				
					ALV	WAY	′S	OPEN						

Figure 2-2. GENI DIP Switch Assignments

2.6 OIU DIP Switches

The MAIN circuit board is equipped with a bank of 6 "DIP" switches. These switches are accessable by removal of the metal back cover. **The user should never need to change the default position(s).** The default positions are indicated in **BOLD** below. These switches are used to configure the following OIU options:



Figure 2-3. MAIN board DIP Switch Assignments

2.7 Logicmaster 90-70 Configuration

The 90-70 Genius Bus Controller must be configured by Logicmaster to communicate with the OIU. The proper settings are as follows:

GENI-based device	e
Config Mode:	manual
To:	(bit type memory)*
Input Length:	8

*the proper bit memory type (%I, %M, %G, etc.) will be determined by GE Fanuc and Universal Automation

2.8 FloPro Configuration

Consult documentation provided with Universal Automation FloPro for the configuration of Remote Message Units (OIUs) in FloPro. Future editions of this manual may provide this information for convenience.

The OIU module is designed for panel mounting. The drawing below illustrates the panel cutout required for OIU module mounting. All dimensions shown in brackets are in millimeters, and those shown without brackets are in inches.



Following is the wiring diagram for the RS-232 cable for communications between the OIU910 serial port and the PowerMate Motion Controller Serial Port..



The following chart lists the characters which are displayable by the 4-line by 20 character vacuum fluorescent display. The ASCII code for each character is indicated by the row (first digit 0-F in hex) and the column (second digit 0-F in hex) in which the character resides. For instance, the character "q" is represented by ASCII code 17H.

2nd 1st	0	1	2	3	4	5	6	7	8	9	Α	В	С	D	Е	F
0		DP		0	@	Ρ	`	р	Ç	É	á	α	§	À		\leq
1		DC	!	1	А	Q	а	q	ü	æ	í	β		È		\sim
2		DC	"	2	В	R	b	r	é	Æ	ó	γ		Ù		≠
3	DE		#	3	С	S	С	S	â	ô	ú	Δ	ſ	Ë		\bot
4	DI		\$	4	D	Т	d	t	ä	ö	ñ	ε				8
5			%	5	Е	U	е	u	à	ò	Ñ	η		Â		ж
6			&	6	F	V	f	v	å	û		θ	2	Ê		
7			'	7	G	W	g	w	Ç	ù		λ	3	Î		\oplus
8	ВS		(8	Н	Х	h	х	ê	ÿ	Ś	μ		Ô		θ
9	нт)	9	I	Y	i	у	ë	Ö		П	\checkmark	Û		\leftarrow
А	LF		*	:	J	Ζ	j	z	è	Ü	٦	ρ	±			\rightarrow
В			+	-,	K	[k	{	ï	¢	1⁄2	σ		Г		
С			,	<	L	١	Ι		î	£	1⁄4	τ				
D	CR		-	=	Μ]	m	}	ì	¥	i	φ	UF			
Ε				>	Ν	^	n	~	Ä		«	Ω	UF			
F		RS	/	?	0		0		Å	f	»	Σ	UF		o	

Characters with second digit "E" (column E above) are Russian Letters